

TRIM[®] OE315 NS

Vegetable Ester Based Cutting Oil

TRIM OE315 NS is a heavy-duty neat cutting oil formulated using renewable vegetable esters. For use in very tough machining operations of hardened steel alloys, tool steels and stainless steels. TRIM OE315 NS is especially effective in deep hole drilling applications due to its reasonably low viscosity, lubricity and EP performance.

Neat Oils



Neatly to the point-of-cut:

TRIM[®] neat oils, used "neat" without dilution of water, provide maximum lubricity. Typically used for operations such as sliding head machines, honing, grinding very difficult-to-machine materials, and gun drilling.

Depending on the specific product, some TRIM neat oils are a high-end blend of various base oils; while others contain extreme-pressure additives to control built-up edge and prolong tool life.

Get neatly to the cut with TRIM neat oils.



Choose OE315 NS:

- Excellent extreme-pressure additive package for efficient metal removal
- Extremely high lubricity ensures fantastic tool life
- Low viscosity ensures excellent chip removal in deep-hole drilling
- Ester based formulation ensures very low misting potential
- Very high flash point
- Good oxidation stability
- Compatible with copper containing alloys
- Light colour and low odour for good operator acceptance

OE315 NS especially for:

Applications — deep hole drilling, drilling, gear cutting, gun drilling, machining, milling, reaming, tapping, turning

Metals — aluminium, Inconel[®], nickel alloys, stainless steels, steel alloys, titanium and yellow metals

Industries — aerospace, automotive, general industry and medical

OE315 NS is free of — chlorine and zinc

Health and Safety

Request SDS



TRIM[®] OE315 NS

Vegetable Ester Based Cutting Oil



Application Guidelines

- TRIM OE315 NS is designed to be used neat.
- For additional product application information, including performance optimisation, please contact your Master Fluid Solutions' Authorised Distributor at <https://www.masterfluids.com/eu/en/distributors/index.php>, your District Sales Manager, or call our Tech Line at +49 211 77 92 85 - 13.

Physical Properties Typical Data

Colour	Pale straw
Odour	Mild
Form	Liquid
Flash Point	> 230°C
Viscosity	15.00 mm ² /s @40°C

Ordering Information

204-litre drum

1000-litre IBC

TRIM[®] OE315 NS | ©2012-2022 Master Fluid Solutions™ | 2022-08-03

Additional Information

- Consult Master Fluid Solutions before using on any metals or applications not specifically recommended.
- This product should not be mixed with other metalworking fluids or metalworking fluid additives, except as recommended by Master Fluid Solutions, as this may reduce overall performance, result in adverse health effects, or damage the machine tool and parts. If contamination occurs, please contact Master Fluid Solutions for recommended action.
- TRIM[®] is a registered trademark of Master Chemical Corporation d/b/a Master Fluid Solutions.
- The information herein is given in good faith and believed current as of the date of publication and should apply to the current formula version. Because conditions of use are beyond our control, no guarantee, representation or warranty expressed or implied is made. Consult Master Fluid Solutions for further information. For the most recent version of this document, please go to this URL:

https://2trim.us/di/?i=eu_en_OE315NS



Hasselsstraße 6-14
Düsseldorf, 40597
Germany
+49 211 77 92 85 - 0

info-eu@masterfluidsolutions.com

[masterfluids.com/eu/en/](https://www.masterfluids.com/eu/en/)